

## **INSTRUCTIONS**

**OTY** 

1

1

Δ

AWARNING

You must fully read, understand and follow these warnings and instructions (written and video)! Failure to follow these instructions may cause serious injury or death!!

## PARTS LIST

10917

10635

60419

## BOX CONTENTS

EST. 1981 PN TREESTANDS 10917 60419

PNDESCRIPTION10917RSX FOAM SEAT60419ALUMINUM SEAT PAN10635SELF TAPPING SCREWS



 Un-snap and remove the original foam seat from the Seat Perimeter Bar as shown in *figure 1*.
Position the Aluminum Seat Pan on top of the Seat Perimeter Bar as shown in *figure 2*. Secure using 4 Self Tapping Screws at the locations shown in *figure 3*. A powered screw driver is recommended for this step.
Position the RSX Foam seat as shown in *figure 4*. Slide the seat down over the Seat Perimeter Bar / Seat Pan.
The finished seat should look like *figure 5*.

The Aluminum Seat Pan should stay attached at all times. It can be used with both seats.



