

Instructions for repairing cuts and abrasions on your Viper or Cobra Climbing Treestand Cables.

Simply follow the directions below to repair cuts, nicks and abrasions on your treestand cables. To shrink the heat shrink tubing, use either a hair dryer set on "High Heat" or a propane torch. If using a propane torch, use caution not to scorch the heat shrink tubing.

