

Revised Pak-Mule tailgate bracket instructions.

3/3/05

Summit Treestands, LLC - ATV Division
715 Summit Dr.
Decatur, AL 35601
256-353-0634 Phone - 256-353-9818 Fax

Please make sure your Pak-Mule trailer has the following parts included in the hardware packet:



- A. 2 X Rubber coated bracket
- B. 2 X Rubber coated hook
- C. 4 X ¼ X 20 lock nuts
- D. 4 X ¼ X 20 X 1.75" bolts

1. Attach brackets as shown in Figure 1 and 2. Leave brackets loose enough so they can be moved.
2. Take tail gate assembly to ATV rack and spread brackets so they are as far apart as possible. The hooks will always face down.
3. Tighten bracket hardware.
4. Mount tailgate to the bed as shown in main instructions – hooks facing forward. Lift the trailer up and set the hooks down over the ATV cargo rack as shown in Figure 3 and 4. Use supplied utility strap to cinch trailer down as shown in the main instructions.

Figure



Figure 1.



Figure 2.



Figure 4.



Figure 3.