

E. 1 - Rubber Mallet

Step 1: Install Fluted legs into top

Step 2: Insert back, side and front panels into fluted legs

Step 3: Install Middle/Bottom Shelf (depending on model number)

Step 4: Using a rubber mallet, tap the four corners of the shelf to secure cabinet pack