



H. Wilson Company

555 West Taft Drive
South Holland, IL 60473
Phone: 800-245-7224
Fax: 800-245-8224
www.hwilson.com
sales@hwilson.com

Parts List:

- (1) Monitor Lock Set
- (1) Bag of screws

You Will Need:

A drill and 1/8" bit to drill pilot holes
Drill or phillips screwdriver for screws
Masking Tape to mark positioning

WLCDL Assembly Instructions



Instructions: *Please read before beginning assembly.

1. Identify all parts.
2. Place monitor in desired location on desk top.
3. Place four pieces of monitor lock onto base of monitor. Piece with locking mechanism should be in the back. The two shorter pieces will be on the sides and the longer piece without the lock will be in the front. Closed edge on all pieces will be facing outwards.
4. Mark location of outer edge on desk. (Masking tape can be used). This ensures proper placement.
5. Remove monitor.
6. Place one piece back into it's space that you have marked with the tape.
7. With a pencil, mark the position of the screw holes that are in the bottom plate.
8. Repeat steps 6 and 7 until the position of all the screw holes in all four peices have been marked.
9. With the pieces set aside, drill pilot holes into the spaces that you marked.
10. One at a time, place the pieces back in place and secure with screws in the pilot holes.
11. Place monitor back into position and flip the edges down to secure the monitor.

To Set Your Personal Combination:

1. Set up the code-setting switch behind the door lock as indicated in figure A, then set the numbers at front to desired combination.
2. Restore code-setting switch to Figure B, then the combination is set.

Figure A

