

Summit Gun Holder

Installation Instructions

Verify that you have the correct parts as shown in **Figure 1**. Your Gun Holder should include two of these assemblies.

The Gun Holder will fit best on either side of the stand on the angled arm that runs up to the cable as shown in **Figure 2**.

The Holder will also fit on the front bar ONLY IF it has an overall width of 1 3/8" as shown in **Figure 3**. It **WILL NOT** fit on a front bar with an overall width of 1 1/8" as also shown in **Figure 3**. It will still fit the side arms on stands with either size.

Installation instructions for mounting on the side arms:

- Step 1.** Remove the long bolt and wing nut and set aside.
- Step 2.** Remove the clamp and set it aside.
- Step 3.** Remove the 1.25 extension piece and set it aside (see **Figure 1**, this part will not be reused.)
- Step 4.** Insert the long bolt through hole #2 on the base (see **Figure 1**.)
- Step 5.** Reinstall the clamp on the Base oriented as shown in **Figure 4**.
- Step 6.** Reinstall the wing nut and leave it loose.
- Step 7.** Position the upper holder a few inches below the cable bracket. Position the lower holder about 12" down on the arm. Tighten both wing nuts to secure.
- Step 8.** Loosen Holder wing nut to adjust the angle to fit your rifle.

NOTE: The clamp can be reversed 180 degrees to fit stands with 3/4" square tube.

Installation instructions for mounting on 1 3/8" front tubing:

- Step 1.** Reinstall the 1.25 Extension piece on the base.
- Step 2.** Reinstall the clamp on the Base oriented as shown in **Figure 4**.
- Step 3.** Attach holder around frame and tighten the wing nut to secure.
- Step 4.** Assembly should look like **Figure 5** after install.

