



SUMMIT
EST. 1981
TREESTANDS

Replacement Seats
85071 - 85075 - 85117 - 85124 - 85147 - 85148

INSTRUCTIONS

NOTICE

The foam seat included with these treestands is removable for storage. **DO NOT** leave your stand outdoors when it is not being used.

NOTICE

The PN 85071, 85117, 85148 seats can be used facing the tree on Summit 180 and 180 Max model stands **ONLY!**

1. Position the seat inside of the seat climber frame.
2. Wrap the seat strap webbing over the frame from the inside out as shown in *figure 1*.
3. Turn the three bar slide slightly sideways and push it through the metal D buckle that is sewn onto the end of the strap (*figure 2*).
4. Repeat for the other three straps.

PN 85117 and 85148

These seats have straps attached to the sides of the seat. Loop these over the arm rest bars and snap to secure.

PN 85071, 85117 and 85148

These seats have an additional strap directly in the middle of the backrest. Secure this strap around the front perimeter bar while the seat is facing the tree as shown in *figure 3*.



FORM# 11812, 7/2010