

Instructions for Summit Gun Holder

Your new Summit Gun holder, PN 85042, should include 2 of the following (Figure 1):

--- www.summitstands.com ---




Figure 1



Figure 2

The Gun Holder will fit best on the two side arms that run up to the cable as seen in Figure 2. The Gun Holder will also fit on the front bar IF it has an overall width of 1 3/8" (Figure 3).



Figure 3



Figure 4



Figure 5

The Gun Holder will not fit on a front bar with an overall width of 1 1/8" (Figure 4). It will still fit on the side rails of these stands.

If mounting the Gun Holder as shown in Figure 2:

1. Remove the long bolt and wing nut and set aside.
2. Remove clamp and set aside.
3. Remove 1.25 extension piece and set aside (Figure 1, will not be reused).
4. Insert long bolt through hole #2 on base (Figure 1).
5. Reinstall clamp as shown in Figure 5.
6. Reinstall wing nut as shown in Figure 5.
7. Loosen wing nut and attach holder around tubing. Tighten wing nut.
8. NOTE: Clamp can be reversed to fit 3/4" tubing also.

If mounting the Gun Holder as shown in Figure 3 & 6:

1. Make sure 1.25 extension piece is on the base.
2. Make sure Clamp is installed as shown in Figure 5.
3. Loosen wing nut and attach holder around tubing. Tighten wing nut.



Figure 6