Endura Models LE-DUO and LEL-DUO Instruction Sheet - Multi-Height Endura Video Tables

lent Luxor product. Congratulations for having chosen an excel-

enclosing a "satisfaction guaranteed" company. As a service to you, we are tion guarantee. Luxor is a service oriented ing our assistance simply fill out the card and fax it to us toll-free or mail postage paid to request card. Should a problem arise need-Luxor. Be sure to include your telephone Your purchase is backed by Luxor's satisfac-

> number. Upon receipt of your service with your purchase. be sure that you will be completely satisfied request, we will give it immediate attention to

Customer Service Dept Thank you for your confidence.





34"High Model

26'High Model





42'High Model







EL-DUO

PARTS LIST

1 - Endura shelf w/ handle 1 - Endura shelf w/ casters sockets Model LE-DUO

- 1 Endura shelf w/eight leg posts
- 4 141/4" tubular legs 4 - 61/4" tubular legs
- 4 Casters (2 w/brake) 4 - 173/4" tubular legs
- Grommet pass through
- 2 Sheet metal screws 1 - Plug housing cover
- 1 Rubber Mallet Tools Required:

1 - Slotted Screwdriver

Model LEL-DUO Endura shelf w/ casters sockets

- Endura shelf w/eight leg posts Endura shelf w/ handle
- 1 171/2" tubular legs 4 - 11" tubular legs
- I 19" tubular legs
- 4 Casters (2 w/brake) - 25" tubular legs
- Grommet pass through
- 1 Plug housing cover
- 2 Sheet metal screws

WARRANTY

Waukegan, IL 60087 2245 Delany Road LUXOR

The Luxor Lifetime Warranty:

LE-DUO 16" & 26" Height


The electric unit should be assembled

MPORTANT:

become excessive, will negate the warranty when used for their intended purposes. Use for other purposes, wherein weight loads Luxor Endura Tables are fully warranted and may create a safety hazard.

and


dle of the top shelf as illustrated below. by closing the electric plug housing in the han-Cable Track™ Cord Management System start does not have the Electrical Assembly first. See reverse side. If your Endura table



and LEL-DUO 27" and 40" table have two shelves. LE-DUO 34" and 42" table and LELtables enable you to assemble four different heights in one table. LE-DUO 16" and 26" table DUO 48" and 54" table have three shelves. LE-DUO and LEL-DUO multi-height Endura


HOUSING COVER

LEL-DUO 48" and 54" Height LE-DUO 34" & 42" Height




16"H Table use 61/4" legs. 26"H Table use 173/4" legs. 27"H Table use 171/2" legs. 40"H Table use 25" legs.


smooth surface. Push all 4 legs onto leg posts. Lay top shelf (with handle) ribbed side up on a



surfaces of both shelves. legs until all 4 legs are seated (flush) against the legs and insert leg posts into legs. Using a rubber mallet, firmly hammer bottom shelf into Position bottom shelf, ribbed side up, over the 4



Push the four casters firmly into the holes in rubber mallet to properly seat casters. Turn your Casters must be fully seated. Tap firmly with each corner of the bottom shelf. Important: Endura table right side up.




CORD GUIDE COVER

GROMMET RING

GROMMET CAP



plug unit, then insert grommet cap into grom-met ring. Your Endura Mobile Table is now cord guide cover from grommet cap so equipment plug may be run through grommet to ed. For tables with electric assembly, snap off rubber mallet. Insert grommet cap as illustrat-Install grommet ring by tapping into place with



Using a rubber mallet, firmly hammer bottom shelf into legs until all 4 legs are seated (flush) Position bottom shelf, ribbed side up, over the 4 remaining legs and insert leg posts into legs. against the surfaces of both shelves.

Lay top shelf (with handle) ribbed side up on a smooth surface. Push all 4 legs onto leg

seated (flush) against the surfaces of both mer center shelf into legs until all 4 legs are into legs. Using a rubber mallet, firmly hamside up, over the 4 legs and insert leg posts Position center shelf (with 8 leg posts) ribbed


center shelf.

Push remaining 4 legs into leg posts


으

34"H Table use 614" legs. 12"H Table use 1414" legs. 18"H Table use 11" legs.

4"H Table use 25" legs.



each corner of the bottom shelf. Important: Casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your LP table right side up. It is now ready for use. Push the four casters firmly into the holes in



CORD GUIDE COVER-

GROMMET RING

CABLE GROMMET HOLE

GROMMET CAP

0

Install grommet ring by tapping into place with

ready for use. plug unit, then insert grommet cap into grommet ring. Your Endura Mobile Table is now ment plug may be run through grommet to plug unit, then insert grommet cap into gromcord guide cover from grommet cap so equiped. For tables with electric assembly, snap off rubber mallet. Insert grommet cap as illustrat-