Instruction Sheet Models TVP-44C and TVP-44LTC



Customer Service Dept 2245 Delany Rd Waukegan, IL 60087 Ph: 847/244-1800 • 800/323-4656 Fax: 847/244-1818 • 800/327-1698





Parts List

1 - TVP-44C or 1 - TVP-44LTC

2 - Side Panels

1 - Back Panel

1 - Set of Doors

1 - Handle

4 - Screws

1 - Power Cord

4 - Sure Grip Pads

2 - Casters

2 - Casters With Brake

16 - Caster Bolts


16 - Nuts


16 - Lock Washers

Tools Required: 1/2" Open End Wrench Slotted Screwdriver

Turn your equipment table upside down.

INSTALL SWIVEL CASTERS ON END OF TABLE WITH HANDLE







Bolt goes through hole in cabinet panel first, then through TVP unit then up through caster plate

Replacement parts may be purchased from your Luxor dealer should you encounter a problem with your pneumatic casters.

Part No.	<u>Description</u>
80111	Inner Tube only
80109	8" pneumatic wheel w/o brake
80110	8" pneumatic wheel w/ brake
80000	Tire only



SIDE VIEW OF DOOR



Assembly

- 1. Separate and identify parts. Turn unit upside down. Take back panel and put bottom section in first then hook the top lip of back panel around shelf as illustrated. Take caster bolt, and from inside of cabinet, push through panel, then through TVP Table, then up through plate of caster. Secure with lock washer and nut. NOTE: The side with the handle holes (see step 3) is the side that must get the casters with brake. At this point just put one bolt in the casters. Then when back and sides are in place install door in the same manner.
- 2. Door doesn't have a lip (see door side view step 2). Secure door with bolt, washer and nut. Now all remaining bolts can be installed. Turn unit right side up.
- 3. Install handle using 4 screws. then tap power assembly into "U" bracket and wrap cord around handle. Use plug snap to secure cord. Place sure grip pads on top shelf of TVP44C(LTC) directly under foot pattern of equipment to be put on unit. Unit is now ready for use.