

Assembly Instructions:

WT42BUL

Wilson UL Listed 42" Tuffy Table

CONGRATULATIONS!

You have selected an excellent Wilson product. The assembly instructions on the following pages must be followed exactly and without substitution or omission. This includes installation of all counterweights and ballasts as described on the following page. Also, please refer to the parts list to be sure you have all the necessary parts. Wilson Tuffy Tables have a **LIFETIME WARRANTY** and, for the many reasons listed below, will serve your needs for many years to come.

IMPORTANT NOTICE:

In order for this table to become UL listed it underwent a series of stress tests performed by Underwriters Laboratory. These tests included the table being able to withstand the pressure of the weight of a television and a 10° tilt forward without tipping over. Therefore, the required counterweights must be installed evenly and in the rear legs only. This is shown in the diagram on the following page.

Thank you for your confidence in

Wilson Tuffy Tables

- Easy to assemble
- Durable injection molded thermoplastic
- Shelves and legs made from recyclable material
- Won't chip, warp, dent, crack, rust, or peel
- Innovative cable management system
- Convenient molded-in handle on top shelf
- Exclusive color choices
- Lifetime warranty

Open Tuffy Tables Standard

WT42BUL13	42"H	3 Shelves	34lbs
<i>(UL listed up to 13" TV)</i>			
WT42BUL20	42"H	3 Shelves	49lbs
<i>(UL listed up to 20" TV)</i>			

Cable Clips

Black with black shelves and black legs
Putty with color shelves and putty legs

Seven Exclusive Decorator Color Choices

Black, Red, Blue, Gray, Green, Yellow, and Putty

Shelf and Leg Size

18"D x 24"W with 1½" square legs

Casters:

2-4" swivel casters

Big Wheel Kit:

- (2) 8" Heavy Duty Wheels
- (2) Custom Hub Caps
- (1) Metal Axle
- (2) Metal Axle Push Caps



Parts List for WT42BUL13:

- (1) Top Shelf (with handle)
- (1) Middle Shelf (w/8 leg bosses)
- (1) Bottom Shelf (w/caster inserts)
- (8) 16½" Legs
- (3) Cable Management Clips
- (2) 4" Swivel Casters
- (1) Big Wheel Kit
- (2) 2½lb. Counterweights
- (1) ESS Safety Strap

Parts List for WT42BUL20:

- (1) Top Shelf (with handle)
- (1) Middle Shelf (w/8 leg bosses)
- (1) Bottom Shelf (w/caster inserts)
- (8) 16½" Legs
- (3) Cable Management Clips
- (2) 4" Swivel Casters
- (1) Big Wheel Kit
- (4) 5lb. Counterweights
- (1) ESS Safety Strap

Available Accessories:

Cabinet Pack:

See Cabinet Pack Assembly Instructions

Electrical Assembly:


See Electrical Assembly Instruction Sheet.

Note: The parts of your Tuffy Table were engineered for a tight fit and permanent assembly. Disassembly is discouraged. Shelves may have a slight bow. This bow is designed into the mold to create a tighter fit and will straighten after assembly.

Tools required:
(Rubber mallet)



(Optional metal hammer with block of wood to cushion impact)




IMPORTANT!


For your convenience...
The ELECTRICAL ASSEMBLY should be attached to the top shelf before beginning the regular assembly of your Tuffy Table.

Turn the top shelf, bottom side up, and follow the instructions found in the sealed ELECTRICAL ASSEMBLY packet.


If you ordered your Tuffy Table without an ELECTRICAL ASSEMBLY, proceed with regular assembly of table.




1. Place top shelf on firm surface, underside up. Insert legs onto leg bosses. Pound firmly with rubber mallet. (Insert 1 5lb. counterweight into each rear leg for WT42EUL20. Rear legs are along the same side as electrical assembly mount.)




2. Position middle shelf, underside up, onto legs. Using rubber mallet, firmly seat legs into shelf.




3. Place remaining legs onto leg bosses. Pound firmly with rubber mallet.




4. Insert counterweights into rear legs. Rear legs are along the same side as electrical assembly mount. Insert 1 2 1/2lb. counterweight into each lower rear leg for WT42EUL13 and 1 5lb. counterweight into each rear leg for WT42EUL20.



5. Position bottom shelf, underside up, onto legs. Using rubber mallet, firmly seat legs into shelf.



6. Slide metal axle through molded-in double axle sleeves found on underside of bottom shelf. Affix one wheel on one end of axle. Secure by tapping push nut over axle with rubber mallet. Snap custom hubcap into place. Repeat for other side. Insert two 4" casters in the caster sockets located opposite the big wheel assembly.



4. Insert counterweights into rear legs. Rear legs are along the same side as electrical assembly mount. Insert 1 2 1/2lb. counterweight into each lower rear leg for WT42EUL13 and 1 5lb. counterweight into each rear leg for WT42EUL20.

NOTE: THE ESS SAFETY STRAP MUST BE USED WHEN PLACING MONITORS, TVs, OR OTHER EQUIPMENT ON THE TOP SHELF OF THE TABLE. To properly secure your equipment, place the item on the top shelf of the table and place the ESS strap over the item, so that it is in a position not to slide off when tightened. Place each of the two ends of the ESS strap through the safety strap holes cut into the top shelf of the table. On the underside of the shelf, buckle the two ends of the strap together and firmly tighten.