

H. Wilson Company 555 West Taft Drive South Holland, IL 60473 Phone: (800) 245-7224

Fax: (800) 245-8224 sales@hwilson.com

Open Steel Tables Standard


26"-42"H

3 18" x 24" Shelves

44 lbs.

Parts List for W42AE

- (1) Top Half of Steel Cart
- (1) Bottom Half of Steel Cart
- (4) $\frac{7}{8}$ " Screws with Locking Nuts
- (4) 4" Swivel Casters
- (1) Rubber Mat



<u>W42A</u> Adjustable Height Metal AV Cart



Cart Assembly Instructions:

TWO PEOPLE SHOULD ASSEMBLE THIS CART

- 1. For the adjustable height table, lower top 1/2 of cart over bottom 1/2 of cart lining up the holes on legs to select desired height. Lock into place with $\frac{7}{8}$ " (1)screw and (1) nut on each leg. Screw head should be on the outside of the leg and attached with the nut on the inside of the leg. Make sure that locknuts are very secure before turning cart over.
- 2. Turn cart over. Insert stems of locking casters into the 2 caster sockets on the 18" side of the table from which you will be pushing the table. Insert the two non-locking 4" casters onto the opposite 18" side of the table. Turn cart right side up.