



H. Wilson Company 2245 Delany Road Waukegan, IL 60087 (800) 245-7224 sales@hwilson.com

## Parts List:

- (1) Top shelf with handle & 4 bosses
- (1) Middle shelf with 8 bosses (up & down)
- (1) Bottom Shelf with caster inserts and leg cutout
- (1) Electrical Assembly
- (8) Square Legs
- (2) 4" Swivel casters with brake
- (2) 4" swivel casters
- 1. Follow CASTER Instructions
- 2. Follow LEG Instructions to bottom shelf
- 3. Follow MIDDLE shelf instructions
- 4. Follow TOP SHELF instructions
- 5. Follow CPU holder instructions (in CPU Holder box)
- 6. Follow *Electrical assembly* instructions (in bag with electrical)



## **MIDDLE SHELF**



Middle shelves have 8 bosses. Place the bosses on the underside (ribbed) into the top of the lower legs. Press fit first and tap with mallet if necessary. Place legs onto upper bosses - tap with mallet if necessary



Required Tools (not included)






Rubber Mallet

Optional: metal hammer with block of wood to cushion impact.




LEG (Onto Bottom OR Middle Shelf)



(Bottom) Turn over shelf (shelves). (Any) Press fit legs over bosses. Gently tap with mallet if necessary.

TOP SHELF



Press fit into the top of the final set of legs. Tap gently with mallet if necessary to fully seat.

<u>\*\*\* Final Steps</u> - Attach Electrical Assembly To Molded Bracket As Shown In Packaged Instructions Attach CPU Clamp holder as shown in the packaged instructions