




Instructions for Easy Demand Feeder

THANK YOU for your purchase of the **Easy Demand Feeder**, a top quality Moultrie product. Please read this sheet before assembling this unit. If you should have any questions about this or any other Moultrie product, please contact us using the information at bottom of page.

To help us better serve you, please complete and mail the enclosed Warranty Card


I INSTALLING THE FUNNEL

- 1 Place **Funnel** inside **Drum** with small end of funnel facing down, and attach with two short **Bolts** using provided nuts and washers.



II INSTALLING THE FEED ARM

- 1 Slide **Feed Arm** through **Funnel** with ball outside of bucket.
- 2 Slide **Hanger** through hole in **Feed Arm**.
- 3 Allow **Feed Arm** to slide down into drum until **Hanger** rests on the bottom of the **Drum**.



III ADDING MATERIAL AND HANGING THE FEEDER

- 1 While holding handle, add desired material to the bucket and attach lid.
- 2 Using a chain, rope, or cable, secure the Easy Demand Feeder to a tree limb such that animal's head reaches bottom of Feed Arm. For deer, position bottom of Feed Arm 4 to 6 feet off ground.

TIPS & POINTERS

1: (Q) *When should I fill the drum on my feeder?* (A) To prevent damage to the feeder kit, do not load drum until unit is off the ground.

2: (Q) *What should I hang my feeder with and how high should I hang it?* (A) Some animals will chew through products like rope, so chain or steel cable is best. The bottom of the feeder should be about 7 feet from the ground.

3: (Q) *What kind of feed should I use?* (A) Whole kernel corn is recommended. Whole kernel corn mixed with soybeans or pellets is also effective for attracting deer. NOTE: When not mixed with corn, some pellet type feeds can take on moisture and clog the feeder.



Our Service Department will gladly answer any questions you have. Call 205-664-6700 or 800-653-3334, Monday - Friday, 8:00 AM to 5:00 PM CST. www.moultriefeeders.com