



SUMMIT
EST. 1981
TREESTANDS

INSTRUCTIONS



1 PARTS LIST

BOX CONTENTS		QTY	22029 - FOOTREST HARDWARE KIT	
PN	DESCRIPTION		PN	DESCRIPTION
40123	FOOTREST BAR	1	10601	1 3/4" BOLT, 1/4x20
22029	FOOTREST HARDWARE PACKET	1	10612	LOCK NUT, 1/4x20
			10640	LONG SHANK BUSHING
			10641	SHORT SHANK BUSHING
			10635	SELF TAPPING SCREW
			10668	FOOTREST BUMPER
			10122	FOOTREST MOUNTING BRACKET

2 ASSEMBLY

(Installation is made easier by the use of a powered screwdriver)

1. Insert the Footrest Bracket into the perimeter tube as shown in **figure 1**. This bracket should be placed between the first and second rung from the front of the platform.
2. Secure the bracket with one self tapping screw as shown in **figure 2**. Repeat for the other side.
3. Insert two of the long shank bushings into the pre-punched holes in each end of the footrest tube as shown in **figure 3**.
4. Insert the short shank bushing into the outside of each footrest bracket from **Step 1** (See **figure 4**).
5. Line up the footrest bar on the **INSIDE** of the two footrest brackets and secure one side using the 1 1/2" bolt and lock nut. The gap between the other side of the bar and the bracket is normal at this point.
6. Insert the remaining 1 1/2" bolt through the other side of the footrest bar and pull the bar to the side so that you can tighten the lock nut. If squeaking occurs, loosen the bolts by 1/2 turn.
7. Fold the bar down and note where it crosses the stand frame - make a mark on the footrest at this point. Fold the bar back up. Secure the two rubber bumpers at the mark using the two remaining self tapping screws as shown in **figure 5**. Your finished footrest should look like **figure 6**.



FOOTREST BUMPERS
(PN 10668)

Footrest